4.2.13 Target Pile Air Cooling System

The purpose of the air cooling system is (1) to keep the pit floor and walls at approximately 12.8 °C, (2) to remove the following heat loads: beam heating - 158 kW, stripline - 2.4 kW, ambient - 3.4 kW, fan - 50 kW, (3) to dehumidify at a rate of 20 kilograms/hour at the 158 kW beam heating load, and (4) filter particulates from the airflow. The automatically controlled system is designed to provide 240 kW of cooling, and to circulate and filter 750 Nm³ of air per hour. The high efficiency particulate filters have a minimum removal efficiency of 99.97% with 0.3-micron size particles. The dehumidification rate is based on a leak exchange rate between the target hall and the target pile of 2.5% of the design airflow rate. The filters are installed in bag-in/bag-out housings.

The flow schematic is shown in **Figure 4.2-41 a & b**. It is discussed below, starting where the cooling airflow exits the target pile.

Temperature and humidity of the air exiting the target pile are monitored. Humidity of the target hall is also monitored.

Pressure drop across the particulate and high efficiency filter banks are individually monitored. High differential pressure across either bank will shutdown the fan. It is very important to change the filters at the specified pressure drops. In particular, the prefilter will come apart at high-pressure drops, and unload the particulates trapped in it. This will unnecessarily load the much more expensive high efficiency filters, most likely requiring that they be changed immediately.

The airflow is cooled after filtering. An automatically controlled air damper is installed in parallel with the evaporator coils. It will make moderate adjustments in the amount of air flowing to the evaporators to reduce the reheat duty. Air damper position can also be positioned manually. An electrically operated solenoid valve starts or stops the flow of high-pressure liquid refrigerant 22 to each evaporator coil based on the system heat load. Solenoid valve operation can be either automatic or manual. The full-open and full-closed state of each solenoid valve is monitored using limit switches. A self-operated, thermal expansion valve automatically controls flow of refrigerant 22 to each evaporator coil. Evaporator coil header pressure is used to automatically adjust condenser unit capacity to match the system heat load. Operating status of the condensing unit is monitored.

The single-speed fan boosts the airflow to operating pressure after cooling. Fan differential pressure is monitored. The particle beam will shutdown if fan differential pressure is too low. Fan inlet and outlet temperatures are monitored. The fan can be started and stopped in either the target hall or the power supply room.

The reheater heats the airflow to operating temperature when needed. Reheater operation can be either automatic or manual. The heating element is equipped with a high temperature switch to protect it from burning out. Temperature and humidity of the air entering the target pile are monitored. The particle beam will shutdown if supply air temperature to the target pile is high or low for too long.

Slow start, smart motor contactors energize the fan and refrigeration compressor motors. Each contactor will protect its motor from being damaged by current and voltage irregularities. Each motor winding has an internal high temperature switch that is included in the control logic to further protect the motor from damage.

A PLC, programmable logic controller, is used to automatically control the solenoid valves that start and stop high-pressure refrigerant flow to each evaporator coil. Control logic for the fan is hardwired. All monitoring instruments are wired to PLC input modules. The PLC transmits all monitored signals to Acnet via Ethernet. The signals will be displayed on Actnet parameter pages. Selected signals are included on alarm pages and on graphic displays.

The instrument list is given in **Table 4.2-16.5a** and **Table 4.2-16.5b**.

				NORMAL	NORMAL	CALIBRATION	ACCURACY	ANALOG	DISCRETE	
TAG NO.	DESCRIPTION	LOCATION	UNITS	OPERATING RANGE	OPERATING VALUE	RANGE	[+/-]	SIGNAL	SIGNAL	MANUFACTURE
AE -	Analysis Element - Supply air relative humidity	Local	%	55 to 65		0 - 100				
AE -	Analysis Element - Return air relative humidity	Local	%	30 to 65		0 - 100				
AE -	Analysis Element - Target hall relative humidity	Local	%	50 to 100	-	0 - 100				
AIT -	Analysis Indicating Transmitter - Supply air relative humidity	PSR	%	55 to 65		0 - 100				
AIT -	Analysis Indicating Transmitter - Return air relative humidity	PSR	%	30 to 65		0 - 100				
AIT -	Analysis Indicating Transmitter - Target hall relative humidity	PSR	%	50 to 100		0 - 100				
HC -	Hand control, Open Auto Close - Evaporator #1 upper coil	PSR							0 to 110 VAC	
HC -	Hand control, Open Auto Close - Evaporator #1 lower coil	PSR	-	-	-			-	0 to 110 VAC	
HC -	Hand control, Open Auto Close - Evaporator #2 upper coil	PSR	-	-				-	0 to 110 VAC	
HC-	Hand control, Open Auto Close - Evaporator #2 lower coil	PSR							0 to 110 VAC	
HC -	Hand control, Open Auto Close - Evaporator #3 upper coil	PSR							0 to 110 VAC	
HC -	Hand control, Open Auto Close - Evaporator #3 lower coil	PSR							0 to 110 VAC	
HC -	Hand control, Open Auto Close - Evaporator #1 upper coil	Acnet command to PLC	-	-	-		-	-	-	
HC -	Hand control, Open Auto Close - Evaporator #1 lower coil	Acnet command to PLC	-	-			-	-	-	
HC-	Hand control, Open Auto Close - Evaporator #2 upper coil	Acnet command to PLC								
HC -	Hand control, Open Auto Close - Evaporator #2 lower coil	Acnet command to PLC								
HC -	Hand control, Open Auto Close - Evaporator #3 upper coil	Acnet command to PLC								
HC -	Hand control, Open Auto Close - Evaporator #8 lower coil	Acnet command to PLC	-	-	-		-	-	-	-
HC -	Hand control, Start - Fan	PSR	-	-	-		-	-	0 to 110 VAC	
HC-	Hand control, Start - Fan	Local							0 to 110 VAC	
HC -	Hand control, Stop - Fan	PSR							0 to 110 VAC	
HÇ -	Hand control, Stop - Fan	Local							0 to 110 VAC	
HC -	Hand control, On Off Auto - Reheater	PSR - Vendor panel								
IE -	Current Element - Fan motor	Fan motor contactor	%	55 to 70	65	0 - 100		_to_VDC	0 to 200 m	
ISL -	Current Switch Low - Fan motor (Fan "on" signal to software logic)	Fan motor contactor	%	0 - 100	25 25				0 to 24 VDC	
	Current Switch Low - Fan motor (Fan "on" signal to hardwired logic) Power Light - Reheater on	Fan motor contactor	%	0 - 100	25			-	U to 24 VDC	
JL - PDI -	Power Light - Reheater on Pressure Differential Indicator / Switch - Prefiter bank	PSR - Vendor panel PSR	inches WC	0.7 to 1.3	< 1.5	0 to 3	± 2% FS			D
PDI-	Pressure Differential Indicator / Switch - Prefilter bank Pressure Differential Indicator / Switch - High efficiency filter bank	PSR PSR	inches WC	0.7 to 1.3 1.5 to 3	< 1.5	0 to 3	±2% FS			Dwyer
PDI-	Pressure Differential Indicator / Switch - Flan	PSR	inches WC	10 to 13	12	0 to 15	±2% FS			
PDIT -	Pressure Differential Indicator / Switch - Fan Pressure Differential Transmitter - Fan	PSR	inches WC	10 to 13	12	0 to 15		0 to 10 VDC	-	Dwyer Orange Resear
PDSHH.	Pressure Differential Switch High - Prefilter bank	PSR	inches WC	10 10 13	1.25	0 10 20	1/01/3		D to 24 VDC	Dwyer
PDSHH-	Pressure Differential Switch High - High efficiency filter bank	PSR	inches WC		2.75				0 to 24 VDC	Dwyer
PDSHH-	Pressure Differential Switch High High - Prefiter bank	PSR	inches WC		1.5				0 to 24 VDC	Dwyer
PDSHH-	Pressure Differential Switch High High - High efficiency filter bank	PSR	inches WC		3				0 to 24 VDC	Dwyer
PDSLL -	Pressure Differential Switch Low Low - Fan	PSR	inches WC		8				0 to 24 VDC	Dwyer
PDT -	Pressure Differential Transmitter - Prefilter bank	PSR	inches WC	0.7 to 1.3	< 1.5	0 to 2.5	±0.25% FS	4 to 20 mA		Setra
PDT -	Pressure Differential Transmitter - High efficiency filter bank	PSR	inches WC	1.5 to 3	< 3	0 to 5	±0.25% FS	4 to 20 mA		Setra
PDT -	Pressure Differential Transmitter - Fan	PSR	inches WC	10 to 13	12	0 to 25	±0.25% FS			Setra
PI-	Pressure Indicator - Evaporator coils	PSR	psig	58 to 69	61.75	0 to 100	±2% FS			Dwyer
PIT -	Pressure Transmitter - Evaporator coils	PSR	psig	58 to 69	61.75	0 to 100	±0.11% FS	4 to 20 mA		Setra
TE -	Temperature Element - Return air temperature from target pile	Local	ok.	50 to 80	< 80	40 to 100	±0.5			Minco
TE -	Temperature Element - Supply air temperature to target pile	Local	oft	50 to 60	55	40 to 100	±0.5			Minco
TE -	Temperature Element - Fan inlet temperature	Local	ok	45 to 55	50	40 to 100	±0.5			Minco
TE -	Temperature Element - Fan discharge temperature	Local	ok	50 to 60	55	40 to 100	±0.5	-	-	Minco
TE -	Temperature Element - Target pile pit wall #1 @ horn 1 midpoint	Local	oF.	50 to 60	55	40 to 100	#2	-		Omega
TE -	Temperature Element - Target pile pit wall #2 @ horn 1 midpoint	Local	ok.	50 to 60	55	40 to 100	±2			Omega
TE -	Temperature Element - Target pile pit floor #1 @ horn 1 midpoint	Local	ok	50 to 60	55	40 to 100	±2			Omega
TE -	Temperature Element - Target pile pit floor #2 @ horn 1 midpoint	Local	ok	50 to 60	55	40 to 100	±2			Omega
TE -	Temperature Element - Duratek block inner wall #1 @ hom 1 midpoint	Local	ok	50 to 60	55	40 to 100	#2	-		Omega
TE -	Temperature Element - Duratek block inner wall #2 @ hom 1 midpoint	Local	ok.	50 to 60	55	40 to 100	#2	-	-	Omega
TE -	Temperature Element - Hom 1 carriage support beam @ midpoint	Local	oF.	50 to 60	55	40 to 100	±2			Omega
TE -	Temperature Element - Free air at upstream end of hom 1 carriage	Local	ok.	50 to 60	55	40 to 100	±2			Omega
TIC -	Temperature Indicating Controller - Air damper	PSR	oft	50 to 60	55	40 to 100		4 to 20 mA		
TIC -	Temperature Indicating Controller - Reheater control	PSR - Vendor panel	ok	50 to 60	55	40 to 100		4 to 20 mA	-	
TSH-	Target pile supply air temperature high - Reheater control	PSR - Vendor panel	ok	50 to 65	65					
TSHH.	Heating element temperature high - Reheater control	PSR - Vendor panel	ok							
TSHH -	Target pile supply air temperature high high	Local	ok	50 to 70	70				0 to 24 VDC	
π-	Temperature Transmitter - Fan discharge temperature	PSR	op.	50 to 60	55	40 to 100		4 to 20 mA		
TTI1	Temperature Transmitting Indicator - to PLC	PSR	di	50 to 60	55	40 to 100		4 to 20 mA		
		PSR	or	50 to 60	55	40 to 100		4 to 20 mA		
TTI2	Temperature Transmitting Indicator - to Reheater control	Pak	4	30 10 00					0 to 110 VAC	
TTI2 ZSH-	Position Indicator - Fan contactor closed (auxiliary contact)	Motor contactor		-						
TTI2 ZSH- ZSH-	Position Indicator - Fan contactor closed (auxiliary contact) Position Indicator - Solenoid valve HV-nnn open	Motor contactor Local	-	-					0 to 24 VDC	
TTI2 ZSH- ZSH- ZSH-	Position Indicator - Fan contactor closed (auxiliary contact) Position Indicator - Solencid valve HV-nnn open Position Indicator - Solencid valve HV-nnn open	Motor contactor Local Local		-					0 to 24 VDC	
TTI2 ZSH- ZSH- ZSH- ZSH-	Position Indicator - Fan contactor closed (auxiliary contact) Position Indicator - Solencid valve HV-nnn open Position Indicator - Solencid valve HV-nnn open Position Indicator - Solencid valve HV-nnn open	Motor contactor Local Local							0 to 24 VDC 0 to 24 VDC	
TTI2 ZSH- ZSH- ZSH- ZSH- ZSH-	Position Indicator - Fan contactor closed (suxiliary contact) Position Indicator - Solencial valve HV-Innn open	Motor contactor Local Local Local Local							0 to 24 VDC 0 to 24 VDC 0 to 24 VDC	
TTI2 ZSH- ZSH- ZSH- ZSH- ZSH- ZSH- ZSH-	Pesition Indicator - Fan constator closed (sustainty contact) Position Indicator - Solencial valve HV-inn open	Motor contactor Local Local Local Local Local Local							0 to 24 VDC 0 to 24 VDC 0 to 24 VDC 0 to 24 VDC	
TTI 2 ZSH -	Pelabin Indicator - Pan constator classed (auxiliary contact) Pession Indicator - Solencial valve HV-inno open	Motor contactor Local Local Local Local Local Local Local							0 to 24 VDC 0 to 24 VDC 0 to 24 VDC 0 to 24 VDC 0 to 24 VDC	
TTI2 ZSH -	Pasition Indicator - Fan contactor closed (auxiliary contact) Position Indicator - Solencial valve HV-rnm open	Motor contactor Local Local Local Local Local Local Local Local Local					-		0 to 24 VDC 0 to 24 VDC	
TTI2 ZSH - ZSL - ZSL -	Pesition Indicator - Fan constator closed (sustainty contact) Position Indicator - Solencial valve HV-inn open Position Indicator - Solencial valve HV-inn closed Position Indicator - Solencial valve HV-inn closed	Motor contactor Local							0 to 24 VDC 0 to 24 VDC	
TTI 2 ZSH - ZSL - ZSL -	Pesition Indicator - Fan constator closed (auxiliary contact) Pesition Indicator - Solencial valve HV-inno open Pesition Indicator - Solencial valve HV-inno closed Pesition Indicator - Solencial valve HV-inno closed Pesition Indicator - Solencial valve HV-inno closed	Motor contactor Local					-		0 to 24 VDC 0 to 24 VDC	
TTI 2 ZSH - ZSL - ZSL - ZSL -	Pasition Indicator - Fan contactor closed (auxiliary contact) Position Indicator - Solencial valve HV-rnm open Position Indicator - Solencial valve HV-rnm closed	Motor contactor Local							0 to 24 VDC 0 to 24 VDC	
TTI2 ZSH- ZSH- ZSH- ZSH- ZSH- ZSH- ZSH- ZSH-	Pesition Indicator - Fan constator closed (sustinity contact) Position Indicator - Solencial valve HV-nnn open Pesition Indicator - Solencial valve HV-nnn closed	Motor contactor Local							0 to 24 VDC 0 to 24 VDC	
TTI 2 ZSH - ZSL - ZSL - ZSL - ZSL -	Pelision Indicator - Fan constator closed (auxiliary contact) Pesition Indicator - Solencial valve HV-inn open Pesition Indicator - Solencial valve HV-inn closed	Motor contactor Local							0 to 24 VDC 0 to 24 VDC	
TTI2 ZSH - ZSL -	Pesition Indicator - Fan constator closed (sustinity contact) Position Indicator - Solencial valve HV-nnn open Pesition Indicator - Solencial valve HV-nnn closed	Motor contactor Local							0 to 24 VDC 0 to 24 VDC	
TTI2 ZSH - ZSL -	Pelision Indicator - Fan constator closed (auxiliary contact) Pesition Indicator - Solencial valve HV-inn open Pesition Indicator - Solencial valve HV-inn closed	Motor contactor Local							0 to 24 VDC 0 to 24 VDC	
TTI2 ZSH - ZSL - ZSL - ZSL - ZSL - ZSL - ZTI -	Pasition Indicator - Fan contactor closed (auxiliary contact) Position Indicator - Solencial valve HV-rnm open Position Indicator - Solencial valve HV-rnm closed	Motor contactor Local							0 to 24 VDC 0 to 24 VDC	
TTI2 ZSH - ZSL - ZT - ZT - Energze HV -	Peakion Indicator - Pan contactor closed (auxiliary contact) Position Indicator - Solencial valve HV-inno open Position Indicator - Solencial valve HV-inno closed	Motor contactor Local							0 to 24 VDC 0 to 24 VDC	
TTI 2 ZSH - ZSL - ZT	Peakinn Indicator - Fan constator closed (auxiliary contact) Peakinn Indicator - Solencial valve HV-innr open Peakinn Indicator - Solencial valve HV-innr closed	Motor contactor Local							0 to 24 VDC 0 to 24 VDC	
TTI - 2 ISBH - ISBL - I	Peakion Indicator - Pan contactor closed (auxiliary contact) Position Indicator - Solencial valve HV-inno open Position Indicator - Solencial valve HV-inno closed	Motor contactor Local						4 to 20 mA	0 to 24 VDC 0 to 24 VDC	

Table 4.2-16.5a Air-cooling system instrument list – Part 1

TAG NO.	MODEL NUMBER	INSTRUMENT DESCRIPTION	CABLE	WIRED TO	PLC INPUT MODULES	PLC OUTPUT HARDWIRED TO	PLC OUTPUT MODULES	ACNET PARAMETER PAGE	ACNET GRAPHIC DISPLAY	PLA
AE ·				AIT -						
Æ.				AIT -						
E.				AIT -						
VT -				PLC	AIM1 Ch 1			Yes	Yes	66
ıπ -				PLC	AlM1 Ch 2			Yes	Yes	6
JT -				PLC	AlM1 Ch 3			Yes	Yes	Η.
Ç-				HV-						
D-				HV -						
D-				HV-						
D -				HV-						
0 -				HV-						
0.				HV.						†
0 -								Yes		H
										+
C-		•						Yes		
C -			-					Yes		
-								Yes		
C -								Yes		
C -								Yes		+
										+
				Fan motor contactor control circuit					-	+
C -				Fan motor contactor control circuit						+
C-				Fan motor contactor control circuit						╀
C-				Fan motor contactor control circuit						
-				Vendor panel wiring						
				1.						
L.	On II -			PLC	DIM1 Ch 1			Yes		
L.	On II -			Fan motor contactor						+
	UNII-									+
-	-	•	-	Reheater vendor panel wiring		-	-	-	-	
)I -	Photohelic 3003MR	Differential pressure gauge with two switches	-		-		-	-	-	
01 -	Photohelic 3005MR	Differential pressure gauge with two switches	-	-	-	-	-	-	-	
01-	Photohelic 3015MR	Differential pressure gauge with two switches	-	-		-			-	
OIT -	20107 w/LCD Display	Beryllium copper disphragm with inductive pickup		BPS						
SHH -	On PDI -	Phototransistor actuated SPDT relay, 1.0 amp @30 vdc		PLC	DIM1 Ch 2			Yes		
SHH -	On PDI -	Phototransistor actuated SPDT relay, 1.0 amp @30 vdc		PLC	DIM1 Ch 3			Yes	-	
SHH -	On PDI -	Phototransistor actuated SPDT relay, 1.0 amp @30 vdc		PLC	DIM1 Ch 4	-	-	No	-	
SHH -	On PDI -	Phototransistor actuated SPDT relay, 1.0 amp @30 vdc		PLC	DIM1 Ch 5	-	-	No	-	
SLL -	On PDI -	Phototransistor actuated SPDT relay, 1.0 amp @30 vdc		PLC	DIM1 Ch 6			No	-	
DT -	C-264 Option 717	Variable capacitance		PLC	AlM1 Ch 4			Yes	Yes	1
DT -	C-264 Option 717	Variable capacitance		PLC	AIM1 Ch 5			Yes	Yes	1
										Η.
DT -	C-264 Option 717	Variable capacitance		PLC	AIM1 Ch 6			Yes	Yes	
-	Photohelic A36010S	Pressure gauge with two switches	-	-	-	-	-	-	-	
π-	C-204	Variable capacitance		Refrigerator compressor control	-	-	-		-	
	S457PEZ24	Bendable averaging RTD, 100 Ω at 0 °C		PLC	RTD IM1 Ch 1			Yes	No	
E-	S457PEZ12	Bendable averaging RTD, 100 Ω at 0 °C		TTI -						
	S457PEZ12	Bendable averaging RTD, 100 Ω at 0 °C		PLC	RTD IM1 Ch 2			Yes	No	+
	S457PEZ12	Bendable averaging RTD, 100 Ω at 0 °C		TIC -						╀
		Omegaclad Type J - MgO insulation and metal sheath		PLC	T/C IM1 Ch 1			Yes	No	
		Omegaclad Type J - MgO insulation and metal sheath		PLC	T/C IM1 Ch 2			Yes	No	
		Omegaclad Type J - MgO insulation and metal sheath		PLC	T/C IM1 Ch 3			Yes	No	
		Omegaclad Type J - MgO insulation and metal sheath		PLC	T/C IM1 Ch 4			Yes	No	+
		Omegaclad Type J - MgO insulation and metal sheath		PLC	T/C IM1 Ch 5			Yes	No	+
										⊹
		Omegaclad Type J - MgO insulation and metal sheath		PLC	T/C IM1 Ch 6			Yes	No	
		Omegaclad Type J - MgO insulation and metal sheath		PLC	T/C IM1 Ch 7			Yes	No	
		Omegaclad Type J - MgO insulation and metal sheath		PLC	T/C IM1 Ch 8			Yes	No	
Ç.				Air damper positioner						
Ç.				Reheater SCRs						
H -				Reheater vendor panel wiring						
HH -				Reheater vendor panel wiring						
HH -				PLC	DIM1 Ch 7			Yes		
	On TIC -			PLC	AIM1 Ch 7			Yes		
11				PLC	AIM1 Ch 8			Yes	Yes	
12				Reheater vendor panel						
н.				Fan motor contactor control circuit						+
					DIME OF C			V		+
H -				PLC	DIM1 Ch 8			Yes		1
3H -				PLC	DIM2 Ch 1			Yes		L
н.				PLC	DIM2 Ch 2			Yes		
н-				PLC	DIM2 Ch 3			Yes		
н.				PLC	DIM2 Ch 4			Yes		Т
н.				PLC	DIM2 Ch 5			Yes		†
				PLC				Yes		+
L.					DIM2 Ch 6				<u> </u>	+
L.				PLC	DIM2 Ch 7			Yes		1
L.				PLC	DIM2 Ch 8			Yes		
L.				PLC	DIM3 Ch 1			Yes		
L.				PLC	DIM3 Ch 2			Yes		
L.				PLC	DIM3 Ch 3			Yes		
					5445 0113		- 1	. 60	<u> </u>	
-				ZTI -					<u> </u>	
-				PLC	DIM3 Ch 4	-		Yes		
ergize HV -		-				Solenoid valve to evap #1 upper coil	DOM1 Ch 1			
nergize HV -						Solenoid valve to evap #1 lower coil			-	Т
engize HV -						Solenoid valve to evap #2 upper coil				
									<u> </u>	
ergize HV -	-	•			-	Solenoid valve to evap #2 lower coil			-	
		-		-	-	Solenoid valve to evap #3 upper coil	DOM1 Ch 5	-	-	
ergize HV -						Solenoid valve to evap #3 lower coil				

Table 4.2-16.5b Air-cooling system instrument list – Part 2




Figure 4.2-41a: Air-cooling system flow schematic




Figure 4.2-41b: Legend for Air-cooling system flow schematic